

# **J-Link / J-Trace Getting started**

Document: UM08001  
Software Version: 8.22  
Date: March 19, 2025



A product of SEGGER Microcontroller GmbH

[www.segger.com](http://www.segger.com)

# Table of contents

---

|       |  |   |
|-------|--|---|
| 1     | Introduction .....                       | 3 |
| 1.1   | Overview .....                           | 4 |
| 1.1.1 | Getting started .....                    | 4 |
| 1.1.2 | Supported Cores and tested devices ..... | 4 |
| 1.1.3 | Supported IDEs / debuggers .....         | 4 |
| 1.1.4 | Troubleshooting .....                    | 4 |
| 1.1.5 | Other products of interest .....         | 4 |

# Chapter 1

## Introduction

---

Thank you for choosing J-Link / J-Trace as your debugging and programming solution.

This manual presents a quick start guide for J-Link / J-Trace and the J-Link Software and Documentation Pack, supported on Windows, Linux and MacOS.

SEGGERs motto is "It simply works" which also applies to getting started with debug probes and the related software.



*J-Link - Wiki page*

# 1.1 Overview

## 1.1.1 Getting started

The only thing you have to do is downloading and installing the J-Link Software and Documentation Pack from the [SEGGER homepage](#). It is a free of charge software pack that contains a wide variety of tools used for debugging and production. For more information about what is included in the J-Link Software and Documentation Pack, please refer to:

- [J-Link / J-Trace Manual](#)
- [J-Link Software and Documentation Pack release notes](#)

## 1.1.2 Supported Cores and tested devices

J-Link / J-Trace together with the J-Link Software and Documentation Pack provide support for a wide variety of cores and devices.

For a list of cores and devices supported by J-Link / J-Trace, please refer to:

- [List of supported Cores](#)
- [List of supported Devices](#)

## 1.1.3 Supported IDEs / debuggers

J-Link / J-Trace is supported by all common IDEs on the embedded market. As the J-Link Software and Documentation Pack also comes with a GDB Server, all IDEs supporting the GDB interface are automatically working with J-Link / J-Trace. For a list of tested IDEs, including getting started instructions, please refer to the [SEGGER homepage](#).

## 1.1.4 Troubleshooting

If you have questions or if you encounter issues, we recommend to check out our Wiki first:

- [Troubleshooting guide](#) - Related to issues between PC & Probe or Probe & CPU.
- [J-Trace wiki article](#) - Information and troubleshooting related to TRACE.

If this does not help you out and your J-Link / J-Trace is still within support period (1 year), please feel free to contact our support team via our [support ticket system](#).

### Note

Please do not forget to mention the following points:

- J-Link/J-Trace serial number.
- Information about your target hardware (processor, board, etc.).
- A detailed description of the problem.
- Screenshots of all warnings/errors.
- Output of the J-Link Commander if available.
- Your findings of the signal analysis.

## 1.1.5 Other products of interest

SEGGER provides additional tools (soft- and hardware) to support the user for debugging and production purposes. This chapter provides a small overview of the products that are connected to the J-Link / J-Trace and its software in the closest way.

- [SEGGER Embedded Studio](#) - SEGGERs IDE solution.
- [SEGGER Ozone](#) - SEGGERs debugger solution. Ideal for usage with J-Trace.
- [SEGGER SystemView](#) - SEGGERs code instrumentation tool.

For an overview of all SEGGER products, please refer to the [SEGGER homepage](#).